Assembly Instructions for the Revv 1 Passenger Kit

This written guide will walk you through assembling and attaching the Revv1 Passenger Kit.

Refer to the YouTube assembly video by scanning the QR code below:



Materials Needed

- Ride1Up Hex Keys (3mm, 4mm, 5mm, 6mm)
- 8mm open-end wrench
- Wire cutters or scissors
- Two Zip Ties

Step-by-Step Instructions


Step 1: Unpack and Gather Components

- 1. Work in a spacious area with enough room to move around the bike.
- 2. Remove the battery to prevent the bike from tipping over during installation.
- 3. Open all packaging and confirm you have all tools and parts before starting.
- 4. Keep all hardware secure to avoid losing any small pieces.




Step 2: Remove the Light, Bracket, and Rear Frame Plug


- 1. Cut the zip tie securing the rear light cable.
- 2. Unplug the light and remove it using an 8mm wrench to remove the nuts (save the hardware).
- 3. Unbolt the bracket using a 3mm and 4mm Allen wrench and remove it.
- 4. Pull out the rear frame plug once the bracket is removed.




Step 3: Slide & Secure the Passenger Kit

- 1. Slide the passenger kit into the frame until you can see through the front hole.
- 2. Hold the side plates in place, ensuring the thicker end is facing down.
- 3. Insert the long bolt through one side plate and into the front hole in the frame.
- 4. Install the other side plate the same way and loosely secure it with the short bolt at the end of the long bolt.
- 5. Thread the two medium bolts through the side plates into the passenger kit.
- 6. Once all bolts are in place, tighten them to 3-5 Nm.
- 7. Use two 4mm Allen wrenches to tighten the long bolt securely.







Step 4: Install the Rear Light & Extension Cable

- 1. Mount the rear light onto the passenger kit's light mount.
- 2. Secure the light using two 8mm nuts and washers.
- 3. Plug the extension cable into the light and route it along the frame.
- 4. Connect the extension cable to the wire harness and secure it using a zip tie.





Step 5: Install the Foot Pegs

- 1. Attach the pegs on each side using the provided hex bolts and a hex wrench.
- 2. Ensure the pegs fold up when properly installed.

Step 6: Removing the Basket

- 1. To remove the basket, pull the Connect+ latch located under the basket.
- 2. Lift the basket off the rack.

Final Steps & Important Notes

• Do not exceed 130 lbs of total weight on the passenger kit.

- Revv1's max weight capacity is 360lbs.
- Riding with a passenger affects bike handling—ride with caution.
- Periodically check bolts to ensure they remain secure.
- The passenger must keep their feet on the pegs while riding. Fold pegs up when not in use to avoid pedal striking.
- See the related article on Bike and Rack Weight Capacity by Model for more details.

For any questions or additional assistance, please contact customer support.